



MAKE EVERYTHING SMART

# SMART TECHNOLOGT






# LECTURE

8


# • nRF 24L01

Frequency Range	2.4 GHz ISM Band
Maximum Air Data Rate	2 Mb/s
Modulation Format	GFSK
Max. Output Power	0 dBm
Operating Supply Voltage	1.9 V to 3.6 V
Max. Operating Current	13.5mA
Min. Current(Standby Mode)	26μA
Logic Inputs	5V Tolerant
Communication Range	800+ m (line of sight)



- nRF 24L01

- The module can use 125 different channels which gives a possibility to have a network of 125 independently working modems in one place. Each channel can have up to 6 addresses, or each unit




- PA and LNA?

### What is PA and LNA?

PA stands for Power Amplifier. It only amplifies the signal strength being transmitted from the nRF24L01+ chip. Whereas LNA stands for Low-Noise Amplifier whose function is to take an extremely weak signal from the antenna (usually below microvolts or -100 dBm) and amplify it to a more useful level (usually around 0.5 to 1 V).


The (LNA) of the receive path and the (PA) of the transmit path connect to the antenna through a duplexer, which isolates the two signals and prevents the relatively powerful PA output from overloading the sensitive LNA input.



- PA and LNA?

The nRF24L01+ has a feature called Multiceiver. It is an abbreviation for **M**ultiple **T**ransmitter **S**ingle **R**ec**e**iver

In a multiceiver network each RF channel is logically divided into 6 parallel data channels called data pipes. In other words, the data pipe is one of six logical channels in a single physical RF channel. Each data pipe has its own unique address called a data pipe address. Only one data pipe can receive a packet at a time.



- nRF 24L01

there are three scenarios of how the two nRF24L01 modules interact with each other.

1. Transaction with an acknowledgment:

the transmitter initiates the communication by sending a data packet to the receiver. Once the packet is transmitted, it waits approximately 130  $\mu$ s to receive the acknowledgment packet (ACK packet). When the receiver receives the packet it sends the ACK packet to the transmitter. The transaction ends when the transmitter receives the ACK packet.



- nRF 24L01

there are three scenarios of how the two nRF24L01 modules interact with each other.

## 2. Transaction with a lost data packet:

retransmission is required due to the loss of the transmitted packet. After the packet is transmitted, the transmitter waits to receive the ACK packet.

If the transmitter does not receive it within the auto-retransmit-delay (ARD) time it retransmits the packet. When the receiver receives the retransmitted packet, it transmits the ACK packet thereby terminating the transaction.





- **nRF 24L01**

there are three scenarios of how the two nRF24L01 modules interact with each other.

### 3. Transaction with a lost acknowledgment:


retransmission is required due to loss of ACK packets. Here even though the receiver has received the packet in the first attempt itself, due to the loss of the ACK packet, the transmitter thinks that the receiver has not received the packet.

So after the Auto-Retransmit-Delay timeout, the transmitter retransmits the packet. Now when the receiver receives the packet with the same ID as before, it discards it and sends the ACK packet again. The transaction ends when the transmitter receives the ACK packet.




**CE (Chip Enable)** is an active-high pin. When selected, the nRF24L01 will either transmit or receive, depending on which mode it is currently in.

**CSN (Chip Select Not)** is an active-low pin and is normally kept HIGH. When this pin goes low, the nRF24L01 starts listening on its SPI port for data and processes it accordingly.



## Arduino SPI pins

Arduino	SCK	MISO	MOSI	SS
Uno	13	12	11	10
Nano	13	12	11	10
Mega	52	50	51	53



sketch\_aug18a | Arduino 1.8.13

File Edit Sketch Tools Help

Verify/Compile	Ctrl+R
Upload	Ctrl+U
Upload Using Programmer	Ctrl+Shift+U
Export compiled Binary	Ctrl+Alt+S
Show Sketch Folder	Ctrl+K
Include Library	
Add File...	

```

sketch_
void se
// pu
}

void lo
// put your main code here, to run repeate
}

```

Manage Libraries...	Ctrl+Shift+I
Add .ZIP Library...	
Arduino libraries	
Bridge	
Esplora	
Ethernet	
Firmata	
GSM	
Keyboard	
LiquidCrystal	
Mouse	
Robot Control	
Robot IR Remote	
Robot Motor	

Library Manager

Type All Topic All rf24

library also supports controlling the radio with only 2 pins on ATtiny and ATmega microcontrollers!  
[More info](#)

**RF24 by TMRh20**  
**Radio driver, OSI layer 2 library for nrf24L01(+) modules.** Core library for nRF24L01(+) communication. Simple beginners, but offers advanced configuration options. Many examples are included to demonstrate various mod communication.  
[More info](#)

Version 1.4.2 Install

**RF24Ethernet by TMRh20**  
**OSI layer 4/5 (TCP/IP) wireless/radio IoT mesh networks for nRF24L01(+)** Automated, wireless(not WiFi), ser that communicate/link together using standard protocols & networking. Typically requires Raspberry Pi/Linux de  
 An experiment disconnected...  
[More info](#)

RF24G by Caio Motta

Close

# • Inspection Code

If your serial output has these values then Your nrf module is in working condition :

```
EN_AA          = 0x3f
EN_RXADDR      = 0x02
RF_CH          = 0x4c
RF_SETUP       = 0x03
CONFIG         = 0x0f
```

```
#include <SPI.h>
#include <RF24.h>
#include <printf.h>
```

```
RF24 radio(9, 8);    // CE, CSN pins & create an RF24 object
```

```
byte addresses[][6] = {"1Node", "2Node"};
```

```
void setup() {
    radio.begin(); //begin operation of the chip
    radio.setPALevel(RF24_PA_LOW); //power gain "higher amplitude longer distance
```

Set Power Amplifier (PA) level and Low Noise Amplifier (LNA) state

(decibel-milliwatts) dBm is a unit of level used to indicate that a power level is expressed in decibels (dB) with reference to one milliwatt (mW). It is used in radio, microwave and fiber-optical communication networks

```
radio.openWritingPipe(addresses[0]);
```

Open a pipe for writing via byte array. Old addressing format retained for compatibility.

Only one writing pipe can be opened at once

```
radio.openReadingPipe(1, addresses[1]);
```

Open a pipe for reading

Up to 6 pipes can be open for reading at once. Open all the required reading pipes, and then call [startListening\(\)](#).

level (enum value)	nRF24L01 description
RF24_PA_MIN (0)	-18 dBm
RF24_PA_LOW (1)	-12 dBm
RF24_PA_HIGH (2)	-6 dBm
RF24_PA_MAX (3)	0 dBm

Which pipe to open. Only pipe numbers 0-5 are available  
address of the pipe to open.

- Inspection Code

```
radio.startListening(); //Start listening on the pipes opened for reading.  
Serial.begin(9600);  
  printf_begin();  
  radio.printDetails(); //does nothing if printf is not defined “work with  
#include <printf.h>  
  
}  
  
void loop() {  
  // empty  
  
}
```

## • Transmitter code



```
#include <SPI.h>
#include <nRF24L01.h>
#include <RF24.h>
RF24 radio(9, 8); // CE, CSN
const byte address[6] = "00001"; //address through which two modules communicate.
void setup() {
    radio.begin();
    radio.openWritingPipe(address); // set the transmitter address
    radio.setPALevel(RF24_PA_MIN);
    radio.stopListening(); //Set module as transmitter
}
void loop() {
    const char text[] = "ST Smart";
    radio.write(&text, sizeof(text));
    delay(1000);}
```

**Note** that you can send messages up to 32 bytes at a time, as this is the maximum size of a packet that the nRF24L01+ can handle.



If you need confirmation that the receiver has received the data, the method write() returns a bool value. It returns TRUE when the data reaches the receiver or it returns FALSE if the data is lost

## • Receiver code



```
#include <SPI.h>
#include <nRF24L01.h>
#include <RF24.h>
RF24 radio(9, 8);
const byte address[6] = "00001"; //address through which two modules communicate.
void setup() {
    Serial.begin(9600);
    radio.begin();
    radio.openReadingPipe(0, address); //set the address
    radio.setPALevel(RF24_PA_MIN);
    radio.startListening(); //Set module as receiver
}
void loop() {
    if (radio.available()) { //Read the data if available in buffer
        char text[32] = "";
        radio.read(&text, sizeof(text));
        Serial.println(text);
    }
}
```





# • Transmitter



```
#include <SPI.h>
#include <nRF24L01.h>
#include <RF24.h>
RF24 radio(9, 8);
int joystick[2];
const byte address[6] = "00001";
void setup() {
    radio.begin();
    radio.openWritingPipe(address);
    radio.setPALevel(RF24_PA_MIN);
    radio.stopListening();
}
void loop() {
    joystick[0]=analogRead(A0);
    joystick[1]=analogRead(A1);
    joystick[0]=map(joystick[0],0,1023,0,180);
    joystick[1]=map(joystick[1],0,1023,0,180);
    radio.write(joystick,sizeof(joystick));}
```

# • Receiver



```
#include <SPI.h>
#include <nRF24L01.h>
#include <RF24.h>
#include <Servo.h>
RF24 radio(9, 8);

Servo myservo1,myservo2;

const byte address[6] = "00001";
int joystick[2]={90,90};
void setup() {
  Serial.begin(9600);
  radio.begin();
  radio.openReadingPipe(0, address);
  radio.setPALevel(RF24_PA_MIN);
  radio.startListening();
  myservo1.attach(6);
  myservo2.attach(5);}
```

```
void loop() {
  if ( radio.available()) {
    while (radio.available()) {
      radio.read(joystick,sizeof(joystick));
      Serial.print("VRX= ");
      Serial.print(joystick[0]);
      Serial.print("    VRY= ");
      Serial.println(joystick[1]);
      myservo1.write(joystick[0]);
      myservo2.write(joystick[1]);
    }
  }
}
```

**THANKS**  
**FOR**  
**COMING**

